Bladefish Familiarization / Warning Checklist

1) Read entire User Manual prior to first use.

2) Warnings.
Read warnings on page 2 and 3. Read and review Attached Warning Label

3) Battery Charging (also see "Storage" below)
Fully charge battery for first use.
Never charge wet.
Charge lead fits one way only.
Remove charge lead when battery indicates full charge.
Fully discharge battery once every 30 cycles.

4) BF3000 (DPV003)
Insert red Charge Plug securely (fits one way)
Press and hold both switches to start. If unit doesn't start, release and repeat.
Release either one or both switches to stop.

5) BF5000 (DPV005) – 3 Speed
Insert red Charge Plug securely (fits one way)
Press and hold both switches to start. If unit doesn't start, release and repeat.
Unit always starts in the "Middle" speed.
Release and press either switch quickly to increase speed to "High"
Release and press either switch quickly to decrease speed to "Low"
Release and press either switch quickly to increase speed to "Medium"
Release either one or both switches to stop.

6) Care and Maintenance
Drain front grille after each use.
With red Charge Plug inserted, rinse unit with fresh water.
Remove red Charge Plug.
Rest unit in upright position on stand ribs for storage or charging.

7) Storage
Do not store battery fully charged
Do not store battery fully discharged.
Charge battery at least once every 3 months.

8) Warranty
Limited 6 month warranty from date of purchase by consumer.
Make any claims directly to Innovative Scuba Concepts
Original owner only, not transferable.
Personal use only, does not cover commercial or rental use.
Proof of Purchase required for warranty claim.

⚠ **9)** The Bladefish Seajet is an Electromechanical Device that powers you through the water. It can be dangerous to operate without proper training, experience and knowledge. Improper use or improper response to Bladefish failure can result in severe injury or death. Read and act on the following warnings and recommendations before using the
Bladefish.

⚠ **10)** Never tether the Bladefish to you at any time under any circumstances.

⚠ **11)** Never tape or otherwise secure one trigger down to allow one handed operation.

⚠ **12)** We strongly recommend that anyone using a Bladefish or any other DPV take a DPV course prior to use.

⚠ **13)** Bladefish is a direct-drive electromechanical device and can fail "on" (does The not turn off when triggers are released) or "off" (stops working) due to flooding, component failure, drained battery, etc.

a. Since Bladefish can fail "off" (stops working), never rely on the Bladefish to get you from one spot to another. Always plan your dive so that you do not rely on Bladefish to complete <u>any</u> part of your dive. If Bladefish fails "off" and you can comfortably take it back to the boat or land, do so. If not, leave it behind. Retrieve in the future if possible.
b. Since Bladefish can fail "on" (does not turn off when triggers released) be prepared to either remove red start plug (this will shut the Bladefish off) or release Bladefish and leave it behind. Retrieve in the future if possible.

⚠ **14)** Prior to using the Bladefish in an open water dive, use the Bladefish in shallow water to familiarize yourself with its performance characteristics.

⚠ **15)** Always remove red start plug (called "charge plug" in the User Manual) immediately after every dive. Never leave start plug inserted in Bladefish when not in use.